

Dear Honda Owner

Honda Canada has set up a recommended maintenance schedule. We are providing you with this quick reference guide for your first 216 000kms.

6,000km	Oil change – Type 1
12,000km	Intermediate service – Type 2
18,000km	Oil change – Type 1
24,000km	Major service – Type 3
30,000km	Oil change – Type 1
36,000km	Intermediate service – Type 2
42,000km	Oil change – Type 1
48,000km	Major service – Type 4 including adj. valves
54,000km	Oil change – Type 1
60,000km	Intermediate service – Type 2
66,000km	Oil change – Type 1
72,000km	Major service – Type 3
78,000km	Oil change – Type 1
84,000km	Intermediate service – Type 2
90,000km	Oil change – Type 1
96,000km	Major service – Type 4 including adj. valves
102,000km	Oil change – Type 1
108,000km	Intermediate service – Type 2
114,000km	Oil change – Type 1
120,000km	Major service – Type 3
126,000km	Oil change – Type 1
132,000km	Intermediate service – Type 2
138,000km	Oil change – Type 1
144,000km	Major service – Type 4 including adj. valves
150,000km	Oil change – Type 1
156,000km	Intermediate service – Type 2
162,000km	Oil change – Type 1
168,000km	Major service – Type 3
174,000km	Oil change – Type 1
180,000km	Intermediate service – Type 2
186,000km	Oil change – Type 1
192,000km	Major service – Type 4 including adj. valves
198,000km	Oil change – Type 1
204,000km	Intermediate service – Type 2
210,000km	Oil change – Type 1
216,000km	Major service – Type 3