

Dear Honda Owner

Honda Canada has set up a recommended maintenance schedule. We are providing you with this quick reference guide for your first 288 000kms.

8,000km	Oil change – Type A
16,000km	Intermediate service – Type B
24,000km	Oil change – Type A
32,000km	Major service – Type C
40,000km	Oil change – Type A
48,000km	Intermediate service – Type D including AC filter
56,000km	Oil change – Type A
64,000km	Major service – Type C
72,000km	Oil change – Type A
80,000km	Intermediate service – Type B
88,000km	Oil change – Type A
96,000km	Major service – Type E including AC filter, adj. valves
104,000km	Oil change – Type A
112,000km	Intermediate service – Type B
120,000km	Oil change – Type A
128,000km	Major service – Type C
136,000km	Oil change – Type A
144,000km	Intermediate service – Type D including AC filter
152,000km	Oil change – Type A
160,000km	Major service – Type C
168,000km	Oil change – Type A
176,000km	Intermediate service – Type B
184,000km	Oil change – Type A
192,000km	Major service – Type E including AC filter, adj. valves
200,000km	Oil change – Type A
208,000km	Intermediate service – Type B
216,000km	Oil change – Type A
224,000km	Major service – Type C
232,000km	Oil change – Type A
240,000km	Intermediate service – Type D including AC filter
248,000km	Oil change – Type A
256,000km	Major service – Type C
264,000km	Oil change – Type A
288,000km	Major service – Type E including AC filter, adj. valves